

ViewSonic

There are many different ways you can work with your ViewSonic board. You can either use it connected to your computer or you can use it on its own.

Steps To connect the ViewSonic TV to your computer:



1

Click on the VCastSender icon on your laptop or computer.




2

Enter the code that is showing on the ViewSonic TV. You can see the code in the middle or up in the top. Note: Zeros will have a line through them (0) to distinguish them from o. Then click **OK**



3

Now you can choose how you would like to use the screen:



CAST

Click on **Cast** if you would like to cast your computer screen directly on the TV (if you change things on your screen they show on the TV).

Source: Share full screen ▼

Click on the arrow under Cast to get more options.

Share full screen

Share full screen will wirelessly send your screen to the TV (same as Cast)

Share extend screen

Share extend screen will share a new screen on the TV that you can use by moving your mouse to the screen. This way you can use your computer to do something else.

RECEIVE

Receive will cast the TV screen onto your computer.

Disconnect

Make sure when you are done using the TV to click here to disconnect your screen.