
The Cooling System



Why cooling systems are needed



When fuel is burnt in the engine so much heat is produced that if they weren't cooled the engine's parts would melt!


Types of engine cooling

1. Air Cooling (simple & light weight)


2. Liquid Cooling (more efficient)


Cooling & Ignition Systems

Cylinder Head Fins



Direction of Cooling Air Flow.





What do cooling fins do?

Just like with radiant heating systems, by providing a larger surface area, the cooling fins increase the contact with the surrounding air helping to transfer heat to the air.



Maintenance

Air cooled systems are easy to maintain. ..

- 1. Keep cooling passages clear of debris (grass, leaves, etc.)
- 2. Maintain systems integrity; Keep all cooling tin components attached .

The Magneto Ignition


Purpose/Goal of the Ignition System

- 1. To generate a high enough voltage (16,000 volts) to push electrons across an air gap at the spark plug.
- 2. To have the spark occur at the correct moment in time.




Cooling & Ignition Systems

Background Theory - Magnetic Field's Effect on Conductors





Conductors are affected by magnetic fields.

Michael Faraday



The effect is the same no matter whether the conductor passes through the magnetic field or the magnetic field is passed through the conductor.






https://www.youtube.com/watch?v=Fv6N2WV tkEw



Cooling & Ignition Systems

How this all relates to your engine's ignition system...



Armature (coil of wire)

Magnet embedded in the flywheel



Cooling & Ignition Systems




A small 'air gap' exists between the armature and the flywheel.

This gap is adjustable and must be set to a very exacting tolerance.

The gap cannot be too big or too small.

Air 83P 0.006" - 0.010"



Air Gap Too Big...

The magnetic field will have less effect on the armature and the voltage generated will be low.

Too big

Result:

Electrical push (voltage) will not be strong enough to force electrons across the spark plug gap.

= no spark or intermittent spark



Air Gap Too Small...


Even though the gap may seem ok when the engine is cold, the flywheel will expand as the engine warms up resulting in mechanical contact.

Too small

Result:

Flywheel & Armature contact.

= engine stops or parts damaged



Amazingly, your engine's magneto ignition system produces around 16,000 volts!


Voltage is electrical push or pressure. The high voltage is necessary to be able to force electrons to jump across the spark plug's air gap.



4 Simple steps for adjusting air gap


<u>Step 1</u>

loosen armature screws



<u>Step 2</u>


Rotate flywheel to position magnets away from armature



<u>Step 3</u>

place shim between armature and flywheel then...

press armature against shim and flywheel




Step 4

lightly tighten screws to secure armature

then...

rotate flywheel to remove shim




Testing the Magneto & Sparkplug

Now that the air gap has been set correctly to between 0.006" – 0.010" it is time to test to see if you get a voltage being produced by the Magneto.

If <u>NO VOLTAGE</u> is produced by the Magneto – you will <u>NOT</u> get a spark... 😕



Magneto Tester (Optimum generation will produce a thin blue spark).



<u>**DO NOT**</u> attach the tester to the spark plug for this test.



Connect the magneto tester between the spark plug wire and a good engine ground. (a good ground being any nonpainted metal surface).

Attempt to start the engine by pulling the rewind cord.


If the Magneto is good, you will see a think blue spark/line



If you do not have a Magneto Tester, you can perform a test with just the spark plug.

Remove the spark plug, re-attach the spark plug wire and then ground the spark plug to any nonpainted metal surface on the engine.

Attempt to start the engine by pulling the rewind cord and you should see/hear the spark.



Ensure when you re-install the Spark Plug that you torque it to the correct specification of 1<u>80inlbs</u>, so you get a good ground, and it seals so no gases escape.

Cooling & Ignition Systems



The spark plug test is not an absolute test as it is <u>more</u> <u>difficult for the spark to fire under compression</u>. If the spark plug is questionable, do not hesitate to install a new one.